'Click' to download complete Manual

Gestetner® RICOH® savin®

A156/A212...SERIES

SERVICE MANUAL

RICOH GROUP COMPANIES

PN: RCFM5535

Gestetner®

RICOH®

savin®

A156/A212...SERIES

SERVICE MANUAL

service-repairmanual.com

RICOH GROUP COMPANIES

service-repairmanual.com

Rev. 4/98

Gestetner® RICOH® savin®

A156/A153
A160/A157
A162/A161

FIELD
SERVICE MANUAL

service-repairmanuals.com

PN:RCFM5535

service-repairmanual.com

Rev. 4/98

LEGEND

PRODUCT CODE	COMPANY		
	GESTETNER	RICOH	SAVIN
A156	2635TD	FT5535	9035DL
A153	2635	FT5035	9035
A160	2627TD	FT4527	9027DL
A157	2627	FT4027	9027
A162	2822TD	FT4522	9220DL
A161	2822	FT4022	9220
A207	2740TD	FT5840	9400D
A208	2732	FT5632	9032
A211	2732TD	FT5832	9032D
A206	CMR401A	FT5740	9400L
A204	2740Z	FT5640	9400
A210	CMR321A	FT5732	9032L
A212	—	FT4622	9122
A214	—	FT4822	9122DL

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
1	**3/95**	Original printing
2	**7/95**	A162/A161 addition
3	**5/97**	A207/A208/A211 Addition
4	**12/97**	A212/A214 Addition

service-repairmanual.com

The A204 copier is based on the A153 copier.
The A206 copier is based on the A155 copier.
The A207 copier is based on the A156 copier.
The A208 copier is based on the A157 copier.
The A210 copier is based on the A159 copier.
The A211 copier is based on the A160 copier.
The A212 copier is based on the A161 copier.
The A214 copier is based on the A162 copier.

Only the differences from the base copiers are described in the following pages. Therefore, this documentation should be treated as an insert version of the base copier's service manual, although it has a separate binder. It should always be utilized together with the base copier's service manual.

service-repairmanual.com

WARNING

The Field Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Corporation

service-repairmanual.com

service-repairmanual.com

Table of Contents

1. OVERALL MACHINE INFORMATION

1. SPECIFICATIONS 1-1

2. COMPONENT LAYOUT AND DESCRIPTION

1. MACHINE CONFIGURATION 2-1

1.1 COPIER 2-1

1.2 OPTIONAL EQUIPMENT 2-2

2. MECHANICAL COMPONENT LAYOUT 2-3

3. PAPER PATH 2-6

3.1 NORMAL COPYING 2-6

3.2 DUPLEX COPYING 2-7

4. ELECTRICAL COMPONENT DESCRIPTIONS 2-8

5. DRIVE LAYOUT 2-13

5.1 ALL MODELS 2-13

5.2 A153/A156 2-14

5.3 A157/A160 2-14

3. INSTALLATION

1. INSTALLATION REQUIREMENTS 3-1

1.1 ENVIRONMENT 3-1

1.2 MACHINE LEVEL 3-1

1.3 MINIMUM SPACE REQUIREMENTS 3-2

1.4 POWER REQUIREMENTS 3-3

2. COPIER INSTALLATION 3-4

2.1 ACCESSORY CHECK 3-4

2.2 COPIER INSTALLATION PROCEDURE 3-5

2.3 PAPER SIZE SELECTION 3-13

2.3.1 Paper Feed Station Definition 3-13

2.3.2 Paper Size Selection for Copier Paper Trays 3-14

service-repairmanual.com

2.3.3 Paper Size Selection for the Paper Tray Unit, LCT, and By-pass Feed 3-15
2.3.4 Special Paper Size Selection for the 1st Tray 3-16
2.4 SORTER ADAPTER INSTALLATION (OPTION FOR A157, A159, AND A160 COPIERS ONLY) 3-17
2.4.1 Accessory Check 3-17
2.4.2 Installation Procedure 3-18
2.5 TRAY HEATER INSTALLATION (OPTION) 3-19
2.6 OPTICS ANTI-CONDENSATION HEATER (OPTION) 3-21
2.7 ORIGINAL LENGTH SENSOR FOR APS (OPTION ONLY FOR THE LT/DLT VERSION) 3-23
2.8 ADS SENSOR (OPTION) 3-24
2.9 KEY COUNTER HOLDER (OPTION) 3-25
2.10 BRAND DECAL APPLICATION INSTRUCTIONS (-10 AND -22 COPIERS ONLY) 3-26

4. SERVICE TABLES

1. SERVICE REMARKS 4-1
1.1 HANDLING THE DRUM 4-1
1.2 DRUM UNIT 4-2
1.3 DRUM CHARGE ROLLER 4-2
1.4 OPTICS 4-3
1.5 ERASE LAMP 4-3
1.6 DEVELOPMENT UNIT 4-4
1.7 TRANSFER BELT UNIT 4-4
1.8 CLEANING SECTION IN THE DRUM UNIT 4-5
1.9 ERASE LAMP/PTL/QUENCHING LAMP 4-5
1.10 PAPER FEED 4-5
1.11 FUSING UNIT 4-6
1.12 OTHERS 4-6
2. SERVICE PROGRAM MODE 4-7
2.1 SERVICE PROGRAM MODE OPERATION 4-7
2.1.1 Service Program Mode Access Procedure 4-7
2.1.2 Changing the Value of an SP Mode 4-8

service-repairmanual.com

2.2 MEMORY RESET PROCEDURES 4-9
2.2.1 Resetting Counters 4-9
2.2.2 Reset All Counters: SP7-808 4-10
2.2.3 Drum Initialization: SP3-123 4-11
2.2.4 Reset All Memory (SP5-801) 4-12
2.3 SERVICE PROGRAM MODE TABLE 4-14
2.3.1 Quick Reference 4-14
2.3.2 SP Mode Table 4-19
2.4 UT MODE AND SP MODE CROSS REFERENCE TABLE 4-42
2.5 SP5-803 SENSOR/SWITCH INPUT CHECK 4-43
2.6 SP5-804 ELECTRICAL COMPONENT OUTPUT CHECK 4-46
2.7 SP5-019 PAPER SIZE SETTING 4-48
2.7.1 Paper Size Selection for the Paper Tray Unit, LCT, and By-pass Feed 4-48
2.7.2 Special Paper Size Selection for the 1st Tray 4-50
3. PRACTICAL SP MODE USE TABLE 4-51
3.1 REPLACEMENT AND CLEANING 4-51
3.2 MAJOR ADJUSTMENTS 4-51
3.3 DATA DISPLAY 4-52
4. TEST POINTS (MAIN CONTROL BOARD) 4-53
5. PREVENTIVE MAINTENANCE SCHEDULE 4-54
5.1 PM TABLE 4-54
5.2 REGULAR PM PROCEDURE 4-60
6. SPECIAL TOOLS AND LUBRICANTS 4-64

5. REPLACEMENT AND ADJUSTMENT

1. INNER AND OUTER COVERS 5-1
1.1 OUTER COVER REMOVAL 5-1
1.1.1 Front Cover 5-1
1.1.2 Rear Cover 5-1
1.1.3 Left Cover 5-1

service-repairmanual.com

1.1.4 Front Right Cover 5-2
1.1.5 Rear Right Cover 5-2
1.1.6 Top Cover 5-2
1.1.7 Operation Panel 5-2
1.2 INNER COVER REMOVAL 5-3
1.2.1 Upper Inner Cover 5-3
1.2.2 Lower Right Inner Cover 5-3
1.2.3 Lower Left Inner Cover 5-3
2. OPTICS 5-4
2.1 EXPOSURE GLASS REMOVAL 5-4
2.2 EXPOSURE LAMP REPLACEMENT 5-5
2.3 SCANNER DRIVE BELT REPLACEMENT 5-6
2.4 SCANNER POSITIONING ADJUSTMENT 5-9
2.5 3RD SCANNER MOTOR REPLACEMENT 5-10
2.6 LENS VERTICAL DRIVE MOTOR REPLACEMENT 5-11
3. DEVELOPMENT AND TONER SUPPLY 5-12
3.1 DEVELOPMENT UNIT REMOVAL 5-12
3.2 DEVELOPER REPLACEMENT 5-13
3.3 TONER SUPPLY MOTOR REPLACEMENT 5-15
4. AROUND THE DRUM 5-16
4.1 DRUM UNIT REMOVAL 5-16
4.2 DRUM REPLACEMENT 5-17
4.3 PICK-OFF PAWL REPLACEMENT 5-19
4.4 ID SENSOR BOARD REPLACEMENT 5-20
4.5 DRUM CLEANING BLADE REPLACEMENT 5-21
4.6 PTL BOARD REPLACEMENT 5-23
4.7 QUENCHING LAMP REPLACEMENT 5-24
4.8 ERASE LAMP REPLACEMENT 5-25
4.9 DRUM CHARGE ROLLER REPLACEMENT 5-26
4.10 DRUM CHARGE ROLLER TERMINAL REPLACEMENT 5-27
4.11 DRUM CHARGE ROLLER CLEANER REPLACEMENT 5-28

service-repairmanual.com

5. TRANSFER BELT UNIT 5-29

5.1 TRANSFER BELT UNIT REPLACEMENT 5-29

5.2 TRANSFER BELT REPLACEMENT 5-30

5.3 TRANSFER BELT CLEANING BLADE REPLACEMENT 5-31

5.4 DISPOSING OF COLLECTED TONER 5-32

6. PAPER FEED 5-33

6.1 BY-PASS PICK-UP, FEED, AND SEPARATION ROLLERS, AND TORQUE LIMITER REPLACEMENT 5-33

6.2 PICK-UP, FEED, AND SEPARATION ROLLERS, AND TORQUE LIMITER REPLACEMENT (A153/A155/A156) 5-33

6.3 LOWER PAPER FEED UNIT REPLACEMENT (A153/A155/A156) 5-34

6.4 UPPER PAPER FEED UNIT REPLACEMENT (A153/A155/A156) 5-35

6.5 PAPER FEED ROLLER REPLACEMENT (A157/A159/A160) 5-36

6.6 REGISTRATION SENSOR REPLACEMENT 5-37

6.7 PAPER FEED CLUTCH REPLACEMENT (A157/A159/A160) 5-38

7. LCT 5-39

7.1 LCT UNIT REMOVAL 5-39

7.2 LCT DRIVE BELT REPLACEMENT 5-40

7.3 LCT MOTOR REPLACEMENT 5-41

8. FUSING 5-42

8.1 FUSING UNIT REMOVAL 5-42

8.2 FUSING LAMP REPLACEMENT 5-43

8.3 HOT ROLLER REPLACEMENT 5-44

8.4 PRESSURE ROLLER AND CLEANING ROLLER REPLACEMENT 5-45

8.5 THERMISTOR REPLACEMENT 5-46

servicerepairmanual.com

8.6 THERMOFUSE REPLACEMENT 5-46

9. DUPLEX UNIT 5-47

9.1 FRICTION ROLLER REPLACEMENT 5-47

9.2 DUPLEX FEED ROLLER REPLACEMENT 5-48

9.3 DUPLEX FEED MOTOR REPLACEMENT 5-49

10. COPY QUALITY ADJUSTMENT 5-51

10.1 LIGHT INTENSITY ADJUSTMENT (SP4-001) 5-51

10.2 UNEVEN EXPOSURE ADJUSTMENT 5-53

10.3 IMAGE AREA BIAS VOLTAGE ADJUSTMENT 5-54

10.3.1 Development Bias Adjustment (SP2-201-001) 5-54

10.3.2 Highest ID Level Bias (Manual ID Level 7) Adjustment (SP2-201-002).....5-55

10.4 TONER DENSITY ADJUSTMENT (SP2-203).....5-56

10.5 DETECT/FIXED/TD SENSOR TONER SUPPLY MODE SELECTION (SP2-208-001) 5-57

10.6 AUTOMATIC ID SENSOR ADJUSTMENT (SP3-001) 5-57

10.7 TONER SUPPLY RATIO SELECTION 5-58

10.8 ADS SENSOR AUTOMATIC ADJUSTMENT (SP4-201).....5-59

10.9 ADS DENSITY SELECTION (SP5-106).....5-59

10.10 VERTICAL MAGNIFICATION ADJUSTMENT (SP4-008).....5-60

10.11 HORIZONTAL MAGNIFICATION ADJUSTMENT (SP4-101) 5-61

10.12 FOCUS ADJUSTMENT IN FULL SIZE MODE (SP4-103).....5-62

10.13 FOCUS ADJUSTMENT IN ENLARGE/REDUCE MODE (SP4-102).....5-62

10.14 LEAD EDGE REGISTRATION ADJUSTMENT (SP1-001) 5-62

10.15 LEAD EDGE ERASE MARGIN ADJUSTMENT (SP2-101-001) 5-63

10.16 LENS HORIZONTAL H.P. ADJUSTMENT (SP4-011-001~009).....5-63

10.17 4TH/5TH MIRROR HEIGHT ADJUSTMENT 5-65

servicerepairmanual.com

11. OTHERS 5-66
11.1 MAIN CONTROL BOARD REPLACEMENT 5-66
11.2 AC POWER SUPPLY BOARD REPLACEMENT 5-67
11.3 DC POWER SUPPLY BOARD REPLACEMENT 5-68
11.4 CB HIGH VOLTAGE SUPPLY BOARD REPLACEMENT 5-69
11.5 T HIGH VOLTAGE SUPPLY BOARD REPLACEMENT 5-70

service-repairmanual.com

6. TROUBLESHOOTING

3. COPY QUALITY 6-1
3.1 INTRODUCTION 6-1
3.2 BLANK COPY (WHITE COPY) 6-2
3.3 DIRTY BACKGROUND 6-5
3.4 UNEVEN IMAGE DENSITY 6-9
3.5 VERTICAL BLACK BANDS 6-10
3.6 VERTICAL BLACK LINES 6-11
3.7 VERTICAL WHITE LINES OR BANDS—1 (DULL OR BLURRED) 6-12
3.8 VERTICAL WHITE LINES OR BANDS—2 (THIN, DISTINCT) 6-13
3.9 HORIZONTAL BLACK/WHITE LINES 6-14
3.10 SKEWED (OPTICAL) COPY IMAGE 6-15
3.11 TONER DENSITY TOO HIGH 6-16
3.12 TONER DENSITY TOO LOW 6-18
3.13 TONER SCATTERING 6-20
3.14 UNFUSED COPY 6-21
3.15 A HORIZONTAL THIN LINE APPEARING CLOSE TO THE LEADING EDGE 6-22
3.16 CREASING AFTER FUSING 6-22
3.17 Z-FOLDED COPY OR LEADING EDGE REGISTRATION VARIES 6-22
4. TONER SUPPLY CONTROL 6-23
3. SERVICE CALL CONDITIONS 6-26

3.1 SUMMARY....6-26
3.2 SC CODE TABLE....6-26
3.3 WARNING SC CODE TABLE....6-28
3.4 C-CODE TABLE....6-29
3.5 U-CODE TABLE....6-29
3.6 SC CODE DESCRIPTIONS....6-30
4. BLOWN FUSE CONDITIONS....6-43
5. ELECTRICAL COMPONENT DEFECTS....6-44
5.1 SENSORS....6-44
5.2 SWITCHES....6-47

APPENDIX

PROCESS CONTROL TABLE....1
TABLES & SP MODES FOR PROCESS CONTROL....2
AUTO PROCESS CONTROL TIMING CHART....4

7. DOCUMENT FEEDER A548

1. SPECIFICATIONS....7-1
2. COMPONENT LAYOUT....7-2
2.1 MECHANICAL COMPONENTS....7-2
2.2 ELECTRICAL COMPONENTS....7-3
3. ELECTRICAL COMPONENT DESCRIPTION....7-4
4. INSTALLATION....7-5
4.1 ACCESSORY CHECK....7-5
4.2 INSTALLATION PROCEDURE....7-6
5. SERVICE TABLES....7-7
5.1 DIP SWITCHES....7-7
5.2 VARIABLE RESISTORS....7-8
5.3 LED....7-8
5.4 FUSE....7-8

service-repairmanual.com

6. REPLACEMENT AND ADJUSTMENT 7-9

6.1 TRANSPORT BELT REPLACEMENT 7-9

6.2 FEED ROLLER REPLACEMENT 7-10

6.3 FRICTION BELT REPLACEMENT 7-11

6.4 ORIGINAL SET AND ORIGINAL WIDTH SENSOR REPLACEMENT 7-12

6.5 VERTICAL REGISTRATION ADJUSTMENT 7-13

6.5.1 One Sided Thin Original Mode 7-13

6.5.2 Two Sided Original Mode 7-14

6.6 SIDE-TO-SIDE REGISTRATION (DF POSITIONING) ADJUSTMENT 7-15

8. PAPER TRAY UNIT A549/A550

1. SPECIFICATIONS 8-1

2. COMPONENT LAYOUT 8-2

2.1 MECHANICAL COMPONENT LAYOUT 8-2

2.2 DRIVE LAYOUT 8-3

2.3 ELECTRICAL COMPONENT DESCRIPTION 8-4

3. INSTALLATION 8-5

3.1 ACCESSORY CHECK 8-5

3.2 INSTALLATION PROCEDURE 8-6

3.3 TRAY HEATER (OPTION) 8-8

4. SERVICE TABLES 8-9

4.1 DIP SWITCHES 8-9

4.2 TEST POINTS 8-10

5. REPLACEMENT AND ADJUSTMENT 8-11

5.1 EXTERIOR COVER REMOVAL 8-11

5.2 PAPER FEED CLUTCH REPLACEMENT 8-12

5.3 PAPER FEED UNIT REPLACEMENT 8-13

5.4 FEED ROLLER, PICK-UP ROLLER, AND REVERSE ROLLER REPLACEMENT 8-14

service-repairmanual.com

5.5 RELAY SENSOR REPLACEMENT 8-15

9. PAPER TRAY UNIT A553

1. SPECIFICATIONS 9-1

2. COMPONENT LAYOUT 9-2

2.1 MECHANICAL COMPONENT LAYOUT 9-2

2.2 DRIVE LAYOUT 9-2

2.3 ELECTRICAL COMPONENT DESCRIPTION 9-3

3. INSTALLATION 9-4

3.1 ACCESSORY CHECK 9-4

3.2 INSTALLATION PROCEDURE 9-5

3.3 TRAY HEATER (OPTION) 9-7

4. SERVICE TABLES 9-8

4.1 DIP SWITCHES 9-8

4.2 TEST POINTS 9-9

5. REPLACEMENT AND ADJUSTMENT 9-10

5.1 EXTERIOR COVER REMOVAL 9-10

5.2 MAIN MOTOR REPLACEMENT 9-11

5.3 CLUTCH REPLACEMENT 9-12

5.4 FEED ROLLER REPLACEMENT 9-13

5.5 RELAY SENSOR REPLACEMENT 9-14

10. SORTER STAPLER A554

1. SPECIFICATIONS 10-1

2. COMPONENT LAYOUT 10-3

2.1 MECHANICAL COMPONENT LAYOUT 10-3

2.2 DRIVE LAYOUT 10-4

2.3 ELECTRICAL COMPONENT DESCRIPTION 10-5

3. ACCESSORY CHECK 10-7

4. INSTALLATION PROCEDURE 10-8

service-repairmanual.com

5. SERVICE TABLES (MAIN BOARD)..... 10-14
5.1 DIP SWITCHES 10-14
5.2 LED AND VARIABLE RESISTOR 10-14
5.3 TEST POINTS..... 10-14
6. REPLACEMENT AND ADJUSTMENT..... 10-15
6.1 STAPLER REMOVAL 10-15
6.2 GRIP ASSEMBLY REMOVAL 10-16
6.3 BIN REPLACEMENT 10-17
6.4 BIN LIFT WIRE REPLACEMENT 10-20
6.4.1 Wire Removal 10-20
6.4.2 Wire Installation 10-24
6.5 VERTICAL TRANSPORT UNIT REMOVAL 10-25
6.6 MAIN CONTROL BOARD REPLACEMENT AND ADJUSTMENT 10-26
6.6.1 Main Control Board Replacement 10-26
6.6.2 Bin Sensor Adjustment 10-27
6.7 BELT TENSION ADJUSTMENT 10-28
7. ELECTRICAL COMPONENT DEFECTS 10-29
7.1 SENSORS..... 10-29
7.2 SWITCHES 10-32
7.3 FUSES 10-32

11. SORTER STAPLER A555

1. SPECIFICATIONS 11-1
2. COMPONENT LAYOUT 11-3
2.1 MECHANICAL COMPONENT LAYOUT 11-3
2.2 DRIVE LAYOUT 11-4
2.3 ELECTRICAL COMPONENT DESCRIPTION 11-5
3. INSTALLATION..... 11-6
3.1 ACCESSORY CHECK 11-6
3.2 INSTALLATION PROCEDURE..... 11-7

service-repairmanual.com

4. SERVICE TABLES 11-11
4.1 DIP SWITCHES 11-11
4.2 TEST POINTS 11-12
4.3 LED 11-12
4.4 VARIABLE RESISTOR 11-12
5. REPLACEMENT AND ADJUSTMENT 11-13
5.1 EXTERIOR COVER REMOVAL 11-13
5.2 STAPLE UNIT REMOVAL 11-13
5.3 GRIP ARM REPLACEMENT 11-14
5.4 BIN REPLACEMENT 11-15
5.5 TRANSPORT MOTOR REPLACEMENT 11-16
5.6 BIN JAM SENSOR ADJUSTMENT 11-17

12. BIN SORTER A556

1. SPECIFICATIONS 12-1
2. MECHANICAL COMPONENT LAYOUT 12-2
3. ELECTRICAL COMPONENT LAYOUT 12-3
4. ELECTRICAL COMPONENT DESCRIPTIONS 12-4
5. INSTALLATION 12-5
5.1 ACCESSORY CHECK 12-5
5.2 INSTALLATION PROCEDURE 12-6
6. REPLACEMENT AND ADJUSTMENT 12-9
6.1 EXIT ROLLER AND RUBBER BELT REPLACEMENT 12-9
6.2 PAPER SENSOR REPLACEMENT 12-11
6.3 TIMING BELT TENSION ADJUSTMENT 12-12

13. BIN SORTER A557

1. SPECIFICATIONS 13-1
2. COMPONENT LAYOUT 13-2

servicerepairmanual.com

3. ELECTRICAL COMPONENT DESCRIPTIONS 13-3

4. INSTALLATION 13-4

4.1 ACCESSORY CHECK 13-4

4.2 INSTALLATION PROCEDURE 13-5

5. PREPARATION FOR TRANSPORTATION 13-8

6. ROLLER DRIVE BELT REPLACEMENT 13-9

7. BIN GUIDE LUBRICATION 13-10

BULLETINS

service-repairmanual.com